


devolo WiFi Repeater+ ac Installation



devolo

devolo WiFi Repeater+ ac



How to install your devolo WiFi Repeater+ ac

- Method A – configuration using buttons (page 3-7).
- Method B – configuration through the App (page 8).
- Your router's WiFi network (SSID) must be visible.
- Take a look at your routers manual on how to activate the WPS.
- The MAC filter should be disabled during installation.
- If you want to use this device as an access point, please check out the manual.

1a

Method A: Configuration using  button

Plug-In



2a

Wait ~ 80 sec.



3a



4a



*Check router manual for information on WPS button.



Method B: Configuration via App

Download the [devolo Home Network App](#)

An installation assistant will guide you step-by-step through the configuration.

Download now!



🏠 Button		
Duration of the button press	Action	LED behaviour
1-2 sec.	The repeater is connected to the router.	Flashes slowly for a max. of 2 min.

🏠 LED		
The devolo WiFi Repeater+ ac ...		LED behaviour
... is in the start-up process for a max. of 80 seconds.		Lights up red
... the connection to the originating Wi-Fi has been lost, please check e.g. your routers Wi-Fi.		Flashes red
... is being configured via the WPS button.		Flashes slowly white
<ol style="list-style-type: none"> ... is configured successfully. ... has been set up successfully and the connection is in a good state. ... is in access point mode. 		Lights up white
... the data transmission rate is not in the optimal range. (check the app for more information)		Flashes white and red

📶 Wi-Fi button		
Duration of the button press	Action	LED behaviour
1 sec.	WPS function is being carried out	Flashes white

📶 Wi-Fi LED		
The devolo WiFi Repeater+ ac ...		LED behaviour
... is ready to be used by mobile devices.		Lights up white
... is attempting to establish a connection via WPS.		Flashes white
... no longer has any LED function since it was disabled by the user.		Off
... the device is performing an Firmware update.		Flashes quickly

* Download manual for further information (see p. 11).



Further Information

Download Manual here:

<https://www.devolo.com/support/downloads>



Find further information in your language about:

- Installation Assistant
- LED and button behavior
- Network overview
- Access point configuration

Support:

Deutschland	www.devolo.de/service	
Österreich	www.devolo.at/service	
Schweiz/Suisse/Svizzera	www.devolo.ch/service	www.devolo.ch/fr/service
Great Britain	www.devolo.co.uk/service	
France	www.devolo.fr/service	
Italia	www.devolo.it/supporto	
España	www.devolo.es/servicios	
Portugal	www.devolo.pt/Apolo	
Nederlands	www.devolo.nl/service	
Belgien/Belgique/Belgie	www.devolo.be/service	www.devolo.be/fr/service
Sweden	www.devolo.se/support	
Other countries	www.devolo.com/support	

| DE | Garantie: 3 Jahre

Wenden Sie sich bei einem Defekt innerhalb der Garantiezeit bitte an die Service Hotline. Die vollständigen Garantiebedingungen finden Sie auf unserer Webseite www.devolo.com/warranty. Eine Annahme Ihres Gerätes ohne RMA-Nummer sowie eine Annahme unfrei eingesandter Sendungen ist nicht möglich!

| AT | CH | Garantie: 3 Jahre

Ist Ihr devolo-Gerät bei der ersten Inbetriebnahme oder innerhalb der Garantiezeit defekt, wenden Sie sich bitte an Ihren Lieferanten, bei dem Sie das devolo-Produkt gekauft haben. Dieser wird den Umtausch bzw. die Reparatur bei devolo für Sie erledigen. Die vollständigen Garantiebedingungen finden Sie auf unserer Webseite www.devolo.com/warranty.

| FR | CH | BE | NL | Garantie: 3 ans

Si votre appareil devolo présente un défaut lors de la première mise en service ou pendant la période de garantie, veuillez vous adresser au fournisseur chez lequel vous avez acheté le produit devolo. Celui-ci se chargera pour vous du remplacement ou de la réparation auprès de devolo. Vous trouverez l'ensemble des conditions de garantie sur notre site Internet www.devolo.com/warranty.

| GB | SE | FI | NO | DK | Warranty: 3 years

If your devolo device is found to be defective during initial installation or within the warranty period, please contact the vendor who sold you the product. The vendor will take care of the repair or warranty claim for you. The complete warranty conditions can be found at www.devolo.com/warranty.

| IT | CH | Garanzia: 3 anni

Se l'apparecchio devolo alla prima messa in funzione è guasto o si guasta durante il periodo di garanzia, rivolgersi al fornitore presso il quale si è acquistato il prodotto. Questi si occuperà poi della sostituzione o della riparazione presso devolo. Potete trovare le condizioni di garanzia complete sul nostro sito www.devolo.com/warranty.

| BE | NL | Garantie: 3 jaar

Is uw devolo-product bij de eerste ingebruikname (DOA) of in de garantietermijn defect geraakt, neem dan contact op met uw leverancier waar u het devolo product heeft gekocht. Deze zal het product omruilen, of laten repareren bij devolo. De volledige garantievoorwaarden vindt u op onze website www.devolo.com/warranty.

| ES | Garantia: 3 años

Si su dispositivo devolo presenta algún defecto en la primera puesta en marcha o durante el período de garantía, póngase en contacto con el distribuidor donde adquirió el producto. Éste se encargará de la sustitución o reparación del producto devolo. Encontrará las condiciones para la garantía completas en nuestra página web www.devolo.com/warranty.

| PT | Garantia: 3 anos

Se o seu dispositivo devolo apresentar um defeito na primeira colocação em funcionamento ou dentro do período de garantia, dirija-se ao fornecedor onde adquiriu o produto devolo. Este irá, em seu nome, solicitar à devolo que efectue a troca ou reparação do equipamento. Poderá encontrar as condições de garantia completas na nossa página web: www.devolo.com/warranty.

devolo AG
Charlottenburger Allee 67
52068 Aachen
Germany

www.devolo.com